

# MIDI Implementation Chart

Function		Transmitted	Recognized	Remarks
Basic Channel:	Default	1	×	
	Changed	×	×	
Mode	Default	×	×	
	Messages	×	×	
	Altered	*****		
Note Number:	0-127	0-127	×	*1
	True Voice	*****		
Velocity:	Note On	○ 1-127	×	*1
	Note Off	○ 64	×	*1
Aftertouch:	Key's	×	×	
	Channel	×	×	
Pitch Bend		×	×	
Control Change	0-127	○	×	Panel control (Knob, SW, Slider) *1
Program Change:	○ 0-7	○ 0-7	×	*1
	Variable Range	*****	*****	
System Exclusive		○	○	*2
System Common:	Song Position	×	×	
	Song Select	×	×	
	Tune Request	×	×	
System Real Time:	Clock	○	×	
	Commands	×	×	
Aux Messages:	Local On/Off	×	×	
	All Notes Off	×	×	
	Active Sensing	×	×	
	System Reset	×	×	
Remarks	* 1: Only when CH SELECT is set to MIDI CONTROL * 2: In addition to KORG exclusive, DeviceInquiry is also supported.			

Mode 1: OMNI ON, POLY  
Mode 3: OMNI OFF, POLY

Mode 2: OMNI ON, MONO  
Mode 4: OMNI OFF, MONO

○ : Yes  
× : No